

# **Start & Drive**

VAN SECURE COVER

**OPTIMISE THE MAINTENANCE AND REPAIR OF YOUR VEHICLE** 





# Renault Trucks Secure cover provides increased protection for your van.

An ideal option for operators who control their own maintenance, our 'Secure' cover provides you with an annual safety inspection at any Renault Trucks workshop which ensure that your van meets our excellent safety standards.

This extended coverage also entitles you to roadside assistance for any warrantable failures and provides you with an extended period of protection after your warranty has come to an end.

Taking your van for an annual inspection allows our qualified Renault Trucks technicians to spot potential problems before they occur - meaning they are often much less expensive to rectify.

# **Key benefits**

**ROADSIDE ASSISTANCE** in the event of a warrantable failure

ANNUAL INSPECTION at a Renault Trucks workshop

**EXTENDED PROTECTION** for your van after initial warranty ends



Find out more about our Secure cover: Talk to your local dealer or visit renault-trucks.co.uk

		SECURE STANDARD	SECURE MAXI
	Altornator		
DRIVELINE	Alternator		
	Connecting rods and bearings		
	Coolant pump Crank mechanism		_
	Cylinder head, cylinder block		
	Cylinder liner and pistons		
	Electric air pre-heater		
	Engine ECU		
	Fan		_
	Flywheel / flywheel housing		
	Fuel pump		_
	Injection pump		
	Inlet and exhaust manifolds		_
	Intercooler		
	Oil pump and oil cooler		_
	Radiator		
	Starter motor		
	Timing mechanism and Camshaft	-	
	Turbocharger, Turbo compound		
	Valve mechanism and valve cover		
TRANSMISSION	Driveshaft		
	Gear lever, gear shift controls		
	Gearbox / clutch housing		
	Gearbox / gear change ECU		
	Gears, bearing and shafts		
	Oil pump and oil cooler		
	Selector forks		
	Synchronising parts		
	Clutch cylinder		
REAR WHEEL DRIVE	Differential / rear axle housing		
	Differential gear		
	Propeller shaft and bearings		
ELECTRICAL ITEMS	Ad Blue dosing system		
	Cable harness		
	ECUs		
	Immobiliser		
	Info system		
	Radio		
	Relays		
	Windscreen wiper motors		
BRAKES	ABS / EBS brake valves		
	ABS / EBS sensors		•
	Brake valves and pipes		
EXHAUST SYSTEM	Engine after-treatment system		
CHASSIS, SUSPENSION & STEERING	Hubs and wheel bearings		
	Rear wheel bearings		
	Steering		
CAB & INTERIOR	Air conditioning unit		
	Dashboard instruments		
	Driver's seat mechanism		
	Heat regulation and exchanger		
	Rearview mirrors and heating		
	Window mechanism		

Not included in manufacturer packages: bodywork panels, trim, tyres and equipment not supplied by the manufacturer.

# Secure packages

On both the Secure Standard cover and the Secure Maxi cover the following are checked on an annual basis:

# **ELECTRICAL CHECK**

- Dashboard instruments, warning lights and indicator lamps operation
- Fault codes, multifunction information displav
- Fixing condition and connection of batteries
- Lighting condition

# **BRAKE CHECK**

- Braking system
- Brake pads wear, brake lever
- Parking brake operation
- **DRIVELINE CHECK**

# Axles for leakage

- Belts and tensioners condition
- Engine for leakage
- Engine noise and smoke emission
- Gearbox for leakage
- Intake circuit for leakage
- Radiator cores cleanliness
- Transmission play

# SUSPENSIONS / WHEELS CHECK

- Shock absorbers mounting and condition
- Tyre wear and pressure

# **AXLE / STEERING / CHASSIS CHECK**

- General condition of wiring fixings support
- Springs, pads and stabilizer bars condition
- Steering mechanism and front hub bearing

# **CAB CHECK**

- Air conditioning and heating operation\*
- Anti-projection protections, mudflaps condition\*
- Front bumper, license plates, speed limiter disks, radiator grill and lights condition\* General condition of bodywork
- Locks and remote control operation Rear bumper, anti-collision bar condition\*
- Seat belts, horn, screen wipers and
- washers operation Windscreen and rear-view mirrors
  - condition

Wiper blades condition

### **OTHER CHECKS**

- Condition of propshaft joint
- Coupling system condition\*
- Front and rear wheel hubs for leakage
- Fuel tanks for leakage
- General condition and mounting of exhaust line system
- Hoses, ducts and pipes condition
- Hydraulic circuit and gear shift for leakage Level of windscreen wash, coolant, engine
- and steering box oil, brake fluid Power take off for leakage\*
- Presence and mounting of noise shields
- Protection level of coolant circuit condition
- Water presence in compressed air tanks by bleeding

\*Depending on the van's equipment



renault-trucks.co.uk

